



NOTES

1. 1.0 AMP MAX. DRAW
2. ALARM PANEL WIRING NEED NOT BE LARGER THAN #14 AWG. SEE INSTRUCTION MANUAL FOR RECOMMENDED WIRE SIZES.
3. SOURCE & SIGNAL SUPPLIED BY OTHERS, IF USED. CONTACTS SHOWN IN NON-ALARM STATE. CONTACTS RATED 5 AMPS @ 28 VDC/115 VAC.
 * - DENOTES CLOSE TO ALARM
 ⊗ - DENOTES OPEN TO ALARM
4. "GND" TERMINAL IS WIRED (BONDED) TO CABINET (FRAME). THE AC INPUT & DC ALARM CIRCUITS ARE ISOLATED FROM GROUND & EACH OTHER.
5. TERMINALS 5 AND/OR 6 MAY BE USED AS ALARM COMMON.

