


ECVST Automatic Transfer Switch Fire Pump Controller

MASTER



- 1) 115 VAC Input Branch Circuit (50 VA Load) used when Option "K" is supplied.
 - 2) All contact ratings: 5.0 Amp Max. at 115 Vac or 28 Vdc
 - 3) External Circuit Protection Required Unless Option "U" is Provided.
- *-Contacts CLOSE to ALARM ⊗-Contacts OPEN to ALARM

